


ME451: Control Systems

Lecture 12 Time-domain specifications

Dr. Jongeun Choi
Department of Mechanical Engineering
Michigan State University

1

Course roadmap




2

What we do next

- We learned stability.
 - Definition in time domain
 - Condition in s-domain
 - Routh-Hurwitz criterion to check the condition
- Stability is a necessary requirement, but not sufficient in most control problems.
- Specifications other than stability
 - How to evaluate a system quantitatively in time domain?
 - How to give specifications in time domain?
 - What are the corresponding conditions in s-domain?

3

Time response



- We would like to analyze a system property by applying a **test input** $r(t)$ and observing a time response $y(t)$.
- Time response is divided as

$$y(t) = \underbrace{y_t(t)} + \underbrace{y_{ss}(t)}$$

Transient response


$$\lim_{t \rightarrow \infty} y_t(t) = 0$$

Steady-state response

(after y_t dies out)

4

Example of transient & steady-state responses



- Transient response
 $y_t(t) = -3e^{-\frac{t}{2}}$
- Steady-state resp.
 $y_{ss}(t) = 3$


5

Usage of time responses

- Modeling
 - Some parameters in the system may be estimated by time responses.
- Analysis
 - Evaluate transient and steady-state responses (Satisfactory or not?)
- Design
 - Given design specs in terms of transient and steady-state responses, design controllers satisfying all the design specs.


6

Typical test inputs



7

Steady state value for step test signal




- Suppose that $G(s)$ is stable.
- By the final value theorem:

$$y(t) = \lim_{s \rightarrow 0} sG(s) \frac{R}{s} = RG(0)$$
- Step response converges to some finite value, called **steady state value** y_{ss} .


8

Typical unit step response




9

Steady-state error for reference $u_s(t)$




10

Peak value, peak time, and percent overshoot



11

Delay, rise, and settling times




12

An example revisited

- For the example in a previous slide,
 - Steady-state error : 2
 - Delay time around 1.5 sec
 - Rise time around 5 sec
 - Settling time around 6 sec

Remark: There is no peak in this case, so peak value, peak time and percent overshoot cannot be defined.



13

Remarks on time-domain responses

- **Speed of response** is measured by
 - Rise time, delay time, and settling time
- **Relative stability** is measured by
 - Percent overshoot
- In general
 - Fast response → Large percent overshoot
 - Large percent overshoot → small stability margin
- We need to take trade-off between response speed and stability.

14

Summary and Exercises

- Time response and time domain specifications
 - Time response can be used for
 - Parameter estimation
 - Design specification of the feedback system
 - Time response is difficult to compute analytically, except 1st and 2nd order systems (we'll study later).
- Next
 - When does steady state error become zero?
- Exercises
 - Read about performance of feedback control systems.

15